

Owner's Manual Model MLL-483K



FOR INDOOR USE ONLY!

For indoor use only. Use with Table and Floor lamps using a lamp harp and traditional lampshade.

Minimum harp height 8.5" (included with order). Minimum shade dimensions. 5" wide at top. 12" wide at bottom.

INSTALLING BULBS / REPLACING BULBS:

CAUTION: When installing bulbs, turn off all switches and unplug the lamp from the wall socket to eliminate possible shock hazard. If light bulbs are hot to the touch, please allow bulbs to cool before handling. Do not operate this lamp with missing bulbs or parts.

WARNING: Risk of fire: Do not use this device with any bulbs other than MoreLamplight Reader bulb MLL83A15 or Booster bulb MLL83R20, unless approved by MyLight LLC.


The energy from other light bulb types-incandescent, compact fluorescent and LED – may generate excessive heat and cause damage to your lampshade.

ENERGY USED AND LUMEN OUTPUT.

The moreLamplight retrofit light source houses (4) medium based sockets to operate any combination of 8 Watt MLL83A15 (800 lumens each) or 7 watt MLL83R20 (500 lumens each) directional Booster bulbs. Total watts consumed will range from 28 watts to 32 watts.

CAUTION: Dimming: Use only with Leviton or equivalent Table Top dimmers for portable lamps approved for LED operation.

INSTALLATION:



Unplug your lamp, remove your lamp's shade and its harp.



Install the (4) Reader bulbs in the light sockets



Screw in the adaptor with the bulbs installed. Adjust the housing for the sockets by rotating until the slots are in alignment with the saddle adjacent to your lamp socket. Install the harp.



Note: A harp is included which is the minimum height recommended. If your harp is taller, you should use it for aesthetic reasons.

When the harp has been installed with the column seated in your lamp's socket, tighten the adaptor in the socket by rotating the column at the wide part nearest the socket. The socket holder at the top of the column will remain flexible so it can be rotated in the future if necessary. This is normal.

NOTE:

The housing for the sockets may be rotated easily to allow for harp installation. To align the slots in the housing with the slots in the harp's saddle, screw in the adaptor and hold it in place while rotating the housing. The harp may then be installed. After adaptor is installed, tighten into your lamp's socket by rotating the column clockwise.

TIP:

STRETCH THE LEGS: The two legs of a lamp's harp are flexible and it may be necessary to stretch them out to easily re-install the harp. During harp installation, stretching the legs out makes it easier to allow the harp to fit around the socket housing. The legs will then be returned to their normal position when installed in the lamp's saddle.

For more information or technical support, please visit our website morelamplight.com or call 1-888-211-6305 for support.

YOUR LAMP SWITCH:

With a single (one-way) switch, the Lamplight will also toggle on and off. With a 3 way switch, the light source will operate on 2 of the 3 settings. However, the Lamplight only operates one way—on high.

OPTIONAL DIMMER:

If you wish to vary the range of light, please purchase a dimmer on our website or by calling 1-888-211-6305. **DO NOT USE OTHER DIMMERS, I.E. SUCH AS A WALL SWITCH, WITHOUT CONSULTING THE MANUFACTURER REGARDING LED OPERATION.** Use on other dimmer switches may cause flickering or other problems affecting bulb performance.

BULB OPERATION:

USE OF THE LED READER BULBS AND BOOSTER BULB.

The 4 sockets on the adaptor are designed for a snug fit similar to ordinary bulbs. Once your task is illuminated by moreLamplight, you will notice a remarkable difference in the amount of light (footcandles falling on the surface of your task).

Because many of our customers are engaged in reading or other tasks, i.e., needlework, we have provided a Booster bulb for the socket which has the most impact on your task area. This will often double the dramatic level of illumination you have with the Reader bulb on that task area, i.e., a book.

Some customers have purchased a second Booster bulb to illuminate a larger area such as for quilting or reading a newspaper.

LIFE, LUMENS AND LIGHT LEVELS:

Please refer to your MyLight bulb packages for complete information on the bulbs provided for use with this product.

MoreLamplight optimizes light distribution so that 70% of the light produced is directed down and out where you need it the most. This was accomplished **SPECIFICALLY FOR TABLE AND FLOOR LAMPS BY CONFORMING TO THEIR SIZE AND SHAPE WITHOUT DETRACTING FROM THE AESTHETICS OF YOUR LAMP'S DESIGN.** Some light is also directed upward to contribute indirect light for room ambiance.

Optional table top dimmer.



Slide hand held dimmer for brightness control



Plug your lamp into outlet on the back of the dimmer plug. (Dimmer cord length is six feet.)



Plug in the dimmer to the wall receptacle and operate with the hand held module.



REPLACEMENT BULBS for MyLight Model MLL-483K moreLamplight module.



Product number:
MLL83A15
Reader bulb



Product number:
MLL83R20
Booster bulb



USE AND CARE INSTRUCTIONS:

1. Do not attempt to take the Lamplight adaptor apart. There are no serviceable parts within the housing.
2. Unplug your lamp when changing light bulbs.
3. Never leave any sockets empty when lamp is plugged in.
4. Do not use any bulb other than those approved by MyLight in this device.

For technical support and service, please visit
morelamplight.com or call 1-888-211-6305

© MYLIGHT LLC
3260 Luvan Blvd.
Georgetown, S. Carolina 29440